



**NOTE: ADD 1" THICK ADDITIONAL BLACK FOAM INSULATION FOR SOUND DEADENING PURPOSES, IN WALLS, CEILINGS AND DOORS**

**NOTE:ALL INTERIOR TRIM TO BE INSTALLED WITH NO VISIBLESCREWS**

**NOTE: INSTALL FLOOR TRACK AND POWERSUPPLY FOR THE FUTURE INSTALLATION OF A STRYKER POWERLOAD SYSTEM**